



NOTES

- 1) APPLY CCW-550 PRIMER TO ENTIRE SURFACE AREA.
- 2) APPLY CCW-500R HOT APPLIED WATERPROOFING SYSTEM TO ENTIRE SURFACE AREA.
- 3) INSTALL CCW PROTECTION BOARD
- 4) INSTALL CCW MIRADRAIN DRAINAGE COMPOSITE

NOTE:
INSULATION SHALL BE NON-ABSORBENT,
CLOSED CELL TYPE.

500-10A

INSULATED PLAZA DECK



© 2010 CARLISLE CORPORATION