



NOTES

- 1) APPLY CCW-PRIMER OR CCW-CONTACT ADHESIVE TO ENTIRE SURFACE AREA.
- 2) APPLY CCW-500R HOT APPLIED LIQUID MEMBRANE TO ENTIRE SURFACE AREA.
- 3) INSTALL CCW PROTECTION BOARD
- 4) INSTALL MIRADRAIN DRAINAGE COMPOSITE

CERAMIC TILE INSTALLATION SHALL BE AS RECOMMENDED BY
TILE COUNCIL OF AMERICA

500-10C

MORTAR BED W/ PAVER
PLAZA DECK

CARLISLE

© 2011 CARLISLE CORPORATION