



NOTES

- 1) APPLY CCW-PRIMER OR CCW-CONTACT ADHESIVE TO ENTIRE SURFACE AREA.
- 2) APPLY CCW-500R HOT APPLIED LIQUID MEMBRANE TO ENTIRE SURFACE AREA.
- 3) INSTALL CCW PROTECTION BOARD
- 4) INSTALL MIRADRAIN DRAINAGE COMPOSITE

500-10D

SAND BED W/ PAVER
PLAZA DECK



© 2011 CARLISLE CORPORATION