



NOTES

- 1) INSTALL BACKER ROD. SEALANT DEPTH SHALL EQUAL 1/2 OF JOINT WIDTH, 1/2" MAX.
- 2) INSTALL CCW-201 SEALANT. TOOL FLUSH WITH SURFACE. ALLOW TO CURE OVER NIGHT.
- 3) APPLY CCW-550 PRIMER. 8" ON EACH SIDE OF JOINT.
- 4) INSTALL CCW-711-90 FLASHING, 12" WIDE.
- 5) APPLY CCW-550 PRIMER. APPLY CCW-500R HOT APPLIED MEMBRANE OVER THE ENTIRE SURFACE. (INCLUDING OVER FLASHING)
- 6) INSTALL CCW PROTECTION BOARD H OR HS
- 7) CCW MIRADRAIN DRAINAGE COMPOSITE

500-3A

EXPANSION JOINTS
LESS THAN 1/2"

CARLISLE

© 2007 CARLISLE CORPORATION