



NOTES

- 1) INSTALL BACKER ROD.
SEALANT DEPTH SHALL EQUAL
1/2 OF JOINT WIDTH, 1/2" MAX.
- 2) INSTALL CCW-201 SEALANT.
TOOL FLUSH WITH SURFACE.
ALLOW TO CURE OVER NIGHT.
- 3) APPLY CCW-PRIMER OR
CCW-CONTACT ADHESIVE AT
8" ON EACH SIDE OF JOINT.
- 4) INSTALL CCW-711-90 FLASHING,
12" WIDE.
- 5) APPLY CCW-550 PRIMER.
APPLY CCW-500R HOT APPLIED
MEMBRANE OVER THE ENTIRE
SURFACE.
(INCLUDING OVER FLASHING)
- 6) INSTALL CCW PROTECTION BOARD
H OR HS
- 7) CCW MIRADRAIN DRAINAGE COMPOSITE

500-3A

EXPANSION JOINTS
LESS THAN 1/2"

CARLISLE

© 2011 CARLISLE CORPORATION