



ANY 500-9 TERMINATION DETAIL
 CCW-500 @ 125 mils
 CCW-711-90 mil OR
 CCW UNCURED NEOPRENE FLASHING
 CCW-500 @ 90 mils
 CCW-PROTECTION BOARD H OR HS
 CCW MIRADRAIN 9000 OR 9900
 CCW-500R 215 MIL REINFORCED
 WATERPROOFING SYSTEM

CCW-PRIMER OR
 CCW-CONTACT
 ADHESIVE
 CCW-201 SEALANT
 BACKER ROD
 JOINT FILLER

TERMINATION OF SHEET FLASHING ON WALL SHALL BE BELOW FINISH COURSE

NOTES

- 1) INSTALL BACKER ROD.
(DIA = 1 1/2" X JT WIDTH)
- 2) INSTALL CCW-201 SEALANT.
TOOL SEALANT TO FORM A
1 1/2" X 1 1/2", 45 DEGREE CANT.
- 3) APPLY CCW-PRIMER OR
CCW-CONTACT ADHESIVE TO
TERMINATION POINT ON WALL
AND 10" ONTO DECK.
- 4) INSTALL CCW-711-90 FLASHING.
TERMINATE AT REGLET COUNTER
FLASHING, OR TERMINATION BAR
8" MIN. ABOVE DECK AND 4" MIN.
ONTO DECK.
- 5) APPLY CCW-550 PRIMER.
APPLY CCW-500R HOT APPLIED
MEMBRANE.
- 6) INSTALL CCW PROTECTION BOARD-H
OR HS
- 7) INSTALL CCW MIRADRAIN

500-3B

PERIMETER EXP. JOINT



© 2011 CARLISLE CORPORATION