



### NOTES

- 1) MEMBRANE SPLICING PROCEDURE IS FOR THE SPLICES BETWEEN CLEAN CURED EPDM MEMBRANE AND CCW-500
- 2) VERTICAL EPDM SPLICES SHALL BE OVERLAID WITH 6" WIDE ELASTOFORM FLASHING
- 3) APPLY SPLICING CEMENT OVER ENTIRE 6" MIN. SPLICE AREA OF THE CLEANED CURED EPDM AND ELASTOFORM OVERLAY PRIOR TO THE APPLICATION OF CCW-500
- 4) INSTALL CCW PROTECTION BOARD-H OR HS AND CCW MIRADRAIN DRAINAGE COMPOSITE

500-4A

EXPOSED  
CURB & PARAPET

**CARLISLE**

© 2007 CARLISLE CORPORATION