



NOTES

- 1) CLEAN FLANGE. APPLY CCW-PRIMER OR CCW-CONTACT ADHESIVE TO FLANGE AND 18" ONTO DECK. ALLOW PRIMER TO DRY.
- 2) APPLY 90 MILS OF HOT CCW-500 TO THE DRAIN FLANGE AND 18" OUT ONTO THE DECK.
- 3) INSTALL CCW-711-90 FLASHING, IN A SINGLE 3'X3' PIECE, TO THE DRAIN FLANGE AND DECK. CUT OUT CENTER OF FLASHING FLUSH TO THE INSIDE OF THE DRAIN FLANGE.
- 4) APPLY 125 MILS OF HOT CCW-500 COVERING THE CCW-711-90 FLASHING. SECURE FLASHING IN PLACE UNDER THE CLAMPING RING.
- 5) APPLY CCW-500R HOT APPLIED WATERPROOFING SYSTEM.
- 6) INSTALL CCW PROTECTION BOARD-H OR HS
- 7) INSTALL CCW MIRADRAIN DRAINAGE COMPOSITE

500-6

DOUBLE DRAIN



© 2011 CARLISLE CORPORATION