



### NOTES

- 1) APPLY CCW-PRIMER OR CCW-CONTACT ADHESIVE. APPLY CCW-500-R HOT APPLIED MEMBRANE.
- 2) INSTALL CCW-711-90 FLASHING. TO SPECIFIED HEIGHT AND 4" MIN. ONTO CURED CCW-500.
- 3) APPLY CCW-500 HOT APPLIED MEMBRANE OVER CCW-711-90 FLASHING
- 4) INSTALL CCW PROTECTION BOARD AND MIRADRAIN DRAINAGE COMPOSITE

500-8D

PIPE SLEEVE  
PENETRATION FLASHING

**CARLISLE**

© 2011 CARLISLE CORPORATION