



- METAL COUNTER FLASHING
- CCW-201 SEALANT AND BACKER ROD
- CCW-500 @ 125 mils
- CCW-711-90 FLASHING
- CCW-500 @ 90 mils
- CCW MIRADRAIN 9000, 9800 OR 9900
- CCW-PROTECTION BOARD-H OR HS
- CCW-500 @ 125 mils
- CCW-500 REINFORCING FABRIC
- CCW-500 @ 90 mils
- CCW-550 PRIMER

NOTES

- 1) APPLY CCW-550 PRIMER. APPLY CCW-500-R HOT APPLIED MEMBRANE.
- 2) INSTALL CCW-711-90 FLASHING TO SPECIFIED HEIGHT AND 4" MIN. ONTO CURED CCW-500.
- 3) APPLY CCW-500 HOT APPLIED MEMBRANE OVER CCW-711-90 FLASHING
- 4) INSTALL CCW PROTECTION BOARD AND MIRADRAIN DRAINAGE COMPOSITE

500-8D

PIPE SLEEVE  
PENETRATION FLASHING

