



NOTES

- 1) APPLY CCW-702 PRIMER TO ENTIRE SURFACE AREA.
- 2) APPLY CCW'S 860/861 SYSTEM TO ENTIRE SURFACE AREA.
- 3) AFTER MEMBRANE COOLS, INSTALL CCW PROTECTION BOARD OR CCW MIRADRRAIN DRAINAGE COMPOSITE

WARRANTY NOTES

FOR ULTRA WARRANTY USE CCW MIRADRRAIN AND CCW LIQUI-DECK INSTEAD OF PRIMER

860-10B

PAVER PLAZA DECK



© 2000 CARLISLE CORPORATION