



CERAMIC TILE INSTALLATION SHALL BE AS RECOMMENDED BY
TILE COUNCIL OF AMERICA

NOTES

- 1) APPLY CCW-702 PRIMER TO ENTIRE SURFACE AREA.
- 2) APPLY CCW'S 860/861 SYSTEM TO ENTIRE SURFACE AREA.
- 3) AFTER MEMBRANE COOLS, INSTALL CCW PROTECTION H, HS BOARD OR CCW MIRADRRAIN DRAINAGE COMPOSITE

- MORTAR BED (1 3/4" MIN)
- REINFORCING WIRE OR CLOTH (OPTIONAL)
- CCW PROTECTION BOARD H, HS OR CCW MIRADRRAIN DRAINAGE COMPOSITE
- CCW'S 860/861 SYSTEM
- CCW-702 PRIMER

WARRANTY NOTES

FOR ULTRA WARRANTY USE CCW MIRADRRAIN AND CCW LIQUID-DECK INSTEAD OF PRIMER

860-10C

MORTAR BED W/ PAVER
PLAZA DECK



© 2000 CARLISLE CORPORATION