



NOTES:

1. PRIOR TO INSTALLATION OF SECURTAPE, APPLY SURE-SEAL PRIMER TO SPLICE AREAS.
2. SECURTAPE IS TO BE OVERLAPPED A MINIMUM OF 1" (2.5 cm) AT THE ENDS OF EACH CUT PIECE.
3. LAP SEALANT IS REQUIRED ON "1" JOINT

B-1C

MEMBRANE SPLICE
WITH SecurTAPE™



© 2000 CARLISLE SYNTec INCORPORATED