



NOTES:

1. WALL FLASHING SHALL BE A CONTINUATION OF DECK MEMBRANE
2. TO REPAIR EXPANSION JOINT, USE 3 LAYERS OF ELASTOFORM® FLASHING, OR 1 LAYER OF CURED MEMBRANE

B-3A

EXPANSION JOINTS

**CARLISLE**

© 1996 CARLISLE CORPORATION