



NOTES:

1. TO REPAIR EXPANSION JOINT, USE 3 LAYERS OF ELASTOFORM® FLASHING OR 1 LAYER OF CURED MEMBRANE.
2. SLOPE STRUCTURAL SLAB AWAY FROM EXPANSION JOINT.

B-3B

EXPANSION JOINT

CARLISLE

© 1996 CARLISLE CORPORATION