

INSTALLER CHECK LIST – MiraDRI-860/861

- CCW Representative Contact Information.
- Installer Qualification by CCW
- Verify if components of system match requirements for specified project warranty
- Pre-Construction Meeting - Establish Schedule & Start Date, Warn other Trades not to Damage Membrane
- Use MiraDRI-860, best above 60°F, DO NOT INSTALL if below 40°F.
- Use MiraDRI-861, best below 80°F, DO NOT INSTALL if below 25°F
- In cold or cool weather, keep membrane in warm area prior to application for best adhesion
- For Horizontal Installation - Verify Correct Deck Drainage: Deck Sloped to 2-Stage Drains with 3-inch Flange
- Substrate inspection – Cracks, joints and voids filled. Sharp protrusions ground flush
- Concrete cure time – Minimum 7 days
- Concrete block – Mortar joints struck flush. Droppings cleaned from surfaces
- CCW Product Data Sheets, MSDS's and Shop Drawings
- Have Access to Project Spec and Drawings
- CCW Products: Sheet Waterproofing, Primer, Mastic, Sealant, Drainage Composite, Protection Board, Root Barrier, Insulation
- Tools & Supplies:
 - Seam roller
 - Medium nap roller for primer application
 - Chip brushes for primer installation in corners
 - Utility knife
 - Tape measure
- Safety Equipment
 - Personal Protection Devices and OSHA Approved Safety Equipment for all workers on the jobsite
 - Protective clothing
 - Hard hat